

REFUSE (T774HD)

M2 FREIGHTLINER ASSEMBLY - INSTALLATION GUIDE

KIT #350247TS - FREIGHTLINER M2 MOUNTING ADAPTER					
1.	2.	3.	4.	5.	6.
200152 X2 M8X50MM BOLT	200170 X2 M8X30MM BOLT	200264 X12 M8 FLAT WASHER	200210 X4 10mm SPACER	200216 X4 M8 NYLOCK NUT	330247 X1 M2 BRACKET
					

